

# 47-20 AG/TV Cable

March 24 2003

Includes cc

CCD47-20 Camera 20-41	Voltage at camera 20-41	[ RGO function ]	New Function with CCD47-20	CCD47-20 Pin number	SDSU 20-41
S	0	clk scrn	clock screen	/	S
r	2,-10	I1	I1	7	r
s	2,-10	I2	I2	6	s
k	2,-10	I3	I3	5	k
m	2,-10	S1	S1	30	m
n	2,-10	S2	S2	31	n
t	2,-10	S3	S3	32	t
g	-8,1	H1	R1L	18	g
R	-8,1	H2	R2L	17	R
h	-8,1	H3	R3L,R3R	16,21	h
q	-8,2	PhiR	PhiRR,PhiRL	22,15	q
N	0	VSS	VSS,Pre-amp ground,ABG	3,8,14,23,29,34,33	N
e	8	Vrd	RDL,RDR	10,27	e
J	-6	Vog	OG	9	J
P	-10,2	Vbg	DG	28	B
d	21	Vod	ODR,ODL,ABD	24,13,4	d
f	0	Vabd	Sheath R	Right pre-amp sheath	f
c	0	Vabg	spare		Z
L	0	Vos	AMP_L	Left pre-amp out	L
M	0	Vdos	AMP_R	Right pre-amp out	M
K	0	Vscr	Sheath L	Left pre-amp sheath	K
p	0	analog scrn	analog scrn	/	p
A	0	Chassis	Chassis	/	A
T	0	ID Rtn	ID Rtn	/	T
W	0	ID1	ID1	/	W
X	0	ID2	ID2	/	X
Y	0	ID3	ID3	/	Y
Z	0	ID4	Pre-flash enable	/	i
i	-8,1	n/c	R1R	19	U
j	-8,1	n/c	R2R	20	V
E	0	Temp-	heatsink Temp-	/	E
F	0	Temp+	heatsink Temp+	/	F
D	0	Temp scr	Peltier Status	/	a
G	+9	+9V	Pre-amp Power+	/	G
a	0	Flow sense	CCD Temp	CCD Temp op-amp output	j
b	0	GND	spare	/	b
H	-9	-9V	Pre-amp Power-	/	H
B	+5	Pelt+	Pelt+	/	
C	0	Pelt-	Pelt-	/	
U	12	Fan+	Fan+	/	
V	0	Fan-	Fan-	/	
			temp screen		D

