





SDSU - INGRID

RESET CYCLES



INITIATE READ

ALL RISE AND FALL TIMES APPROX. 250ns

ROW CHANGE

NOTE: GIVEN TIMES MAY CHANGE WITH DIFFERENT SOFTWARE VERSIONS
TIMES SHOWN ARE FOR VERSION 2.3 SOFTWARE.

SDSU - INGRID

READ CYCLES